


The Marble Putter™
Putter Build and Assembly Instructions

To assemble **The Marble Putter™**, take the marble putter head to a Pro Shop or major golf retailer (such as *Golf Galaxy*) and:

1. Select a double-bend putter shaft with a 3/8" offset and .37" bore (tip size) with a 90 degree bore angle. (*The Apollo Stepless Chrome Double-Bend Putter Shaft is ideal.*) Select a shaft that is right-handed or left-handed that matches your putter head.
2. Work with the shop Fitter to determine the ideal length of the shaft. (Standard length is 36".)
3. Select a putter grip and a .37" decorative ferrule.
4. Provide the following items to the Fitter at the shop: **The Marble Putter™** head, ferrule, shaft, and grip. Ask Fitter to assemble as shown:



PUTTER ASSEMBLY